

1. Login as .\administrator
2. Check to see windows is up to date (ex. now it's 21H1), utilize 'Windows Update Assistant' if you must.
3. Take note of the computer hostname for later.
4. Run Delivery Manager Cleanup as admin
5. Run the Pearson Delivery Manager install from \\dbrie1103f01\VUE\VUE Testing Systems\releases\[whatever is the latest release]\app\setup\setup.exe
6. In running the setup, once you see "Test Delivery Workstation" make sure the box is checked. (nothing else)
7. When prompted restart the PC
8. Sign back in as .\administrator
9. Test Delivery Manager to see that it fills the screen, then exit.
10. Right click the network icon on the lower right

11. Click "open network & internet settings"

12. Click "Change Adapter Options".

13. Right Click "Ethernet"

14. Click "Properties"

15. Click and open "Internet Protocol Version 4 Properties"

16. Select "Use the following IP address:" utilizing

IP address: [current IP of machine, found through CMD > Ipconfig]

Subnet Mask: 255.255.252.0 (if still in the 10.14.0.x range)

Default Gateway: 10.14.0.1 (if still in the 10.14.0.x range)

Preferred DNS: 172.16.45.75 } SMCs DNS  
Alternate DNS: 172.20.1.75 } servers

17. Select "validate settings upon exit", click "Ok"

18. Close out any error you might receive doing this if internet is available after, if you can't something was input incorrectly.

19. Restart the machine
20. If machine is in the testing center or it should try to sign into "smc test", if it fails the first time, sign into administrator, sign out, then sign into "smc test" manually, password = smctest12 user = smctest
21. Install veyon
22. In the installer (if on a client machine) deselect "Veyon Master" when prompted.
23. Click Finish with "Run Veyon Configurator now" selected
24. In Veyon Configurator Change "Logon Authentication" to "Key File Authentication".
25. Select the "Authentication keys" tab on the right.
26. Import the public key from the host "SMC Dowagiac Testing Center - public - key.pem"
27. Make sure to erase everything in the naming box except what was in the key name (ex "SMC Dowagiac Testing Center")
28. Click "OK"
29. Click "Apply" and "Yes"

30. Install "LockDown Browser OEM Setup"
31. Set background as corresponding number by finding the picture in "My Pictures > Testing Center Backgrounds - Square"
32. Shut down computer
33. Get to BIOS (F12 > BIOS Setup)
34. Go to "Power Management" > "Wake on LAN"
35. Select "LAN only"
36. Select "Apply"
37. Select "Ok"
38. Exit BIOS
39. Put PWB File inside "Program Files" add "Metro Institute Testing" to desktop.

Make sure the Hostname is correct in the Host Veyon Master, if you cannot see a machines screen on veyon.

Remember to migrate bookmarks